



GENERATIONS AHEAD IN SONAR & ULTRASONIC TECHNOLOGY

Serial Communications Guide



M-300 Family of Low Cost Ultrasonic Sensors

This Manual Covers All M-3xx Model Sensors

MASSA PRODUCTS CORPORATION

280 Lincoln Street
Hingham, MA 02043 U.S.A

Tel. 781-749-4800 • Toll Free in USA: 800-962-7543 • Fax: 781-740-2045 • sales@massa.com

www.massa.com

Copyright © 2007-2015 by Massa Products Corporation. All rights reserved.



Table of Contents

1.0 Introduction	3
2.0 Sensor Wiring	3
3.0 Communications Protocol	3
4.0 Sensor Commands.....	4-8
4.1 Request for STATUS from the M-300.....	4
4.2 Response from M-300 when STATUS information is requested.....	4
4.3 Request to WRITE to the M-300's Data Memory	5
4.4 Request to READ from the M-300's Data Memory	6
4.5 Response from the M-300 to a READ request of Data Memory	6
4.6 Request to SOFTWARE TRIGGER the M-300	7
4.7 Request for M-300 MODEL TYPE and FIRMWARE REVISION LEVE	7
4.8 Response from the M-300 when requesting MODEL TYPE & FIRMWARE REV. LEVEL.....	7
4.9 Response from the M-300 on a SENSOR ERROR.....	8
4.10 Resetting an M-300 ERROR.....	8
4.11 Request to REBOOT the M-300.....	8
5.0 M-300 Data Memory	9-13
5.1 M-300 Data Memory (General)	9-10
5.2 M-300 Data Memory (Linear Mode Parameters)	11
5.3 M-300 Data Memory (Switch Mode Parameters)	12
5.4 M-300 Data Memory (Sensitivity Adjustment Parameters).....	13
6.0 Ultrasonic Waveform.....	14-15
7.0 Flowcharts.....	16-19
M-300 Flowchart for Status Information on Multiple Sensors	16
M-300 Flowchart for Writing to Data Memory.....	17
M-300 Flowchart for Reading Data Memory	18
M-300 Flowchart for Error Processing	19

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated without the prior written consent of Massa Products Corporation.


All specifications are subject to change without notice.

1.0 Introduction

This document was developed for users who want to communicate and control the M-300 Series of Low Cost Smart Ultrasonic Sensors with their own host device. The following pages describe how to obtain Sensor Status information and how to access Data Memory, which controls the sensors operation. Flowcharts in the back of the guide include how to develop routines to implement 32 sensors on line and error handling. Throughout this guide, the term M-300 will mean the line of M-300 Series of Low Cost Smart Sensors.


2.0 Sensor Wiring

A wiring diagram using an RS-232 (DB9) to RS-485 Converter is shown below. You can also use a USB to RS-485 Converter if your PC does not have a RS-232 communications port.



3.0 Communications Protocol

The data rate is set at 19.2 kbaud. Each byte contains 10 bits that include a start bit, 8 bit data, and 1 stop bit and no parity bit. There are a total of 6 bytes required to access the M-300. The M-300 will respond back with 6 bytes that include status (range to target, temperature, target strength, etc), Data Memory read requests, and sensor error messages on the RS-485 bus. Transmitted values are in binary.



4.0 Sensor Commands

4.1 Request for STATUS from the M-300

There are a total of 6 bytes required to obtain the status information from the M-300 that will include target range, temperature, target strength, error condition and other information. The data format of the Status Request from host to sensor is as follows:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32
3	Request Code	3 (status)
4	Placeholder byte	0
5	Placeholder byte	0
6	Checksum	sum of bytes 1 to 5, modulo 256

Note: Request Code 2 can be used to keep it compatible with the M-5000 product line. See Note 3 below.

4.2 Response from M-300 when STATUS information is requested

Upon receiving the Status request, the M-300 will respond back with 6 bytes of Status data with the format defined as:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor ID Tag No.	1 to 32
2	Response Code	8 bits parsed, see below
3	Range data byte (LSB)	see Notes 1, 2, and 3
4	Range data byte (MSB)	see Notes 1, 2, and 3
5	Temperature data	5 to 254, see Note 4 below
6	Checksum byte	Sum of bytes 1 to 5, modulo 256

Response Code data byte 2 parsed:

<u>bit</u>	<u>7</u>	<u>6</u>	<u>5</u>	<u>4</u>	<u>Description</u>	<u>bit</u>	<u>Description</u>
0000					0% target strength	<u>3</u>	Target Detected: 0 =NO 1 =YES
0001					25% target strength	<u>2</u>	Vout operating mode: 0 =Linear 1 =Switch
0010					50% target strength	<u>1</u>	If Switch Mode operation Vout: 0 =0Vout 1 =10Vout else Linear Mode = 0
0011					75% target strength		
0100					100% target strength	<u>0</u>	Set if sensor error, see Data Memory address 104, on page 8 for the error description

Notes:

- 1) Range to target (average): Byte 3 (LSB) combined with byte 4 (MSB) to form 2 bytes, then divided by 128 (inches).
- 2) No target detected will be indicated as 0000 range and 0% target strength.
- 3) If responding to Status Request Code 2, Byte 3 is MSB and Byte 4 is LSB.
- 4) Temperature data is defined as deg C = (byte 5 * 0.48876) – 50.
- 5) See page 8 for the response if there is a sensor error.

4.3 Request to WRITE to the M-300’s Data Memory

There are a total of 6 bytes required to write to the M-300 Data Memory. These locations affect operation of the sensor including sample rate, averaging, loss of echo timeout, Voltage Output operating mode, Sensor ID tag, etc. The description to each Data Memory location is on pages 9-13. The data format is as follows:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32
3	Request Code	103 (write to Data Memory)
4	Address of Data Memory	21 to 104
5	Data to be stored in memory	0 – 255 (limits indicated in Data Memory section of this guide)
6	Checksum	sum of bytes 1 to 5, modulo 256

There is no response from the M-300 after a write request. Good design practice is to read back the Data Memory for verification (see next page). The M-300 will verify that the Data Memory is within specified values as described in the Data Memory description section. Any invalid data will be replaced with the factory default value and will indicate a Data Memory replacement error (please see page 8).

When a write command is initiated, the sensor will stop its normal operation and remain idle waiting for additional writing to the Data Memory. The sensor will only return to normal operation (with the new parameters in Data Memory) when a re-boot command is initiated (see page 8) or if it is re-powered.

SPECIAL CASE: The ID Tag memory address 40 must be unlocked by the command shown here prior to requesting the change. Note that any other command request other than the ID Tag change request will re-lock the ID Tag memory location.

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32
3	Request Code	105 (unlock ID Tag location 40)
4	Unlock value	12
5	Unlock value	234
6	Checksum	sum of bytes 1 to 5, modulo 256

This command must immediately follow with the standard write to Data Memory:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32 (Sensor ID Tag you are requesting to change)
3	Request Code	103 (write to Data Memory)
4	Address of data memory	40
5	New ID Tag	1 to 32
6	Checksum	sum of bytes 1 to 5, modulo 256

The new ID Tag will take affect after a re-boot command (or power cycle).

4.4 Request to READ from the M-300's Data Memory

There are a total of 6 bytes required to access and read the Data Memory from the M-300. The data format is as follows:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32
3	Request Code	104 (read)
4	Address of data memory	21 to 104
5	Placeholder byte	0
6	Checksum	sum of bytes 1 to 5, modulo 256

4.5 Response from the M-300 to a READ request of Data Memory

Upon the M-300 receiving the read request for the specific Data Memory location, the M-300 will respond back with 6 bytes of data with the format defined below:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor ID Tag No.	1 to 32
2	Response Code	128 (read)
3	Address	address of Data Memory
4	Data Memory	data from address in byte 3
5	Data Memory	data from next higher address
6	Checksum	sum of bytes 1 to 5, modulo 256

See pages 9-13 for details on all the Data Memory locations.

4.6 Request to SOFTWARE TRIGGER the M-300

If the M-300's trigger mode is programmed for Software Trigger (memory address 94 = 1), the M-300 will then remain idle until a Software Trigger request occurs. This trigger request will cause the sensor to transmit an ultrasonic pulse and acquire the range to target. Page 9 describes the trigger mode options. See Note 1 below on how long to wait before you request the status information from the sensor. You may also trigger all the sensors wired to the communication bus simultaneously by setting the sensor ID to 0 (zero). This is recommended when sensors are placed in close proximity to each other thus avoiding acoustic cross-talk and erroneous operation. The data format to trigger the M-300 is as follows:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32 (including 0, see Note 2)
3	Request Code	1 (trigger sensor to transmit)
4	Placeholder byte	0
5	Placeholder byte	0
6	Checksum	sum of bytes 1 to 5, modulo 256

Notes:

- 1) After you request a software trigger, you must wait a finite amount of time before you request for status information from the sensor so that it has time to capture the furthest target (model dependant). For the 210 kHz model, wait at least 10mS. For the 150 kHz models, wait at least 15mS. For the 95 kHz model, wait at least 40mS.
- 2) If the Sensor ID Tag (byte 2) is zero, then all sensors on the communications bus will transmit at approximately the same time.
- 3) If setting 4" Min is enabled (M300/150 and M320/150 only), send this command twice to obtain a valid range (ave=1). See Section 5.1.13.

4.7 Request for M-300 MODEL TYPE and FIRMWARE REVISION LEVEL

There are a total of 6 bytes required to access the sensor's model type and firmware revision level. Shown below is the data format required to receive this information:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32
3	Request Code	123 (model type /firmware revision request code)
4	Placeholder byte	0
5	Placeholder byte	0
6	Checksum	sum of bytes 1 to 5, modulo 256

4.8 Response from the M-300 when requesting MODEL TYPE and FIRMWARE REVISION LEVEL

Upon the M-300 receiving the request for Model Type and Firmware Revision Level request, the M-300 will respond back with 6 bytes of data with the format defined below:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor ID Tag No.	1 to 32
2	Response Code	131 (model type /firmware revision response code)
3	Sensor Model Code	100 = M300/210, 101 = M300/95, 102 = M300/150, 142 = M320/150, 141 = M320/95
4	Firmware Revision	data
5	Placeholder byte	0
6	Checksum	sum of bytes 1 to 5, modulo 256

4.9 Response from the M-300 on a SENSOR ERROR

An error is indicated in the Sensor Status response if byte 2 bit 0 = **1**. The Data Memory address 104 will have at least a bit set indicating the source of the error (see Error Flags in the Data Memory Section, page 10). The M-300 will respond back to the normal Status request with 6 bytes as defined below:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor ID Tag No.	1 to 32
2	Response Code	bit 0 is set on error, other bits undetermined
3	Range data byte (LSB)	see note below
4	Range data byte (MSB)	see note below
5	Temperature data	5 to 255 (probe fault if less than 5)
6	Checksum	sum of bytes 1 to 5, modulo 256

Note: Range data bytes will be zero if Data Memory was replaced. Other errors may or may not have valid range. For example, a temperature probe fault error will still try to attempt to obtain a range and report it. An Internal Signal Detect error will report the range as zero and attempts to self correct. A Brown Out error may operate properly, but users should verify their power supply for minimum requirements.

Data Memory address 104 error flags (see page 10):

- If bit 0 set: A Data Memory location was replaced with a factory default value. Sensor sampling operation stops until user clears bit and re-boots the sensor.
- If bit 1 set: Brown out error. Sensor will attempt to self-correct. Verify supply voltage.
- If bit 2 set: Temperature Probe error. Sensor will attempt to self-correct.
- If bit 3 set: Internal Signal Detect error. Sensor will attempt to self-correct

4.10 Resetting an M-300 ERROR

The only two errors that can be reset are the Data Memory replacement and Brown Out errors. This can be done by writing a zero to the memory address **104**. After clearing the error, the sensor must be re-booted (see below). The sensor will attempt to self clear both the Internal Signal detect and Temperature Probe faults. The user cannot clear these errors.

4.11 Request to REBOOT the M-300

There are a total of 6 bytes required to reboot the M-300. This command must be sent after you have completed writing to any or all M-300 Data Memory locations to activate the changes (however re-powering the sensor will also activate the changes). The data structure is as follows:

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32
3	Request Code	119 (reboot)
4	Placeholder byte	0
5	Placeholder byte	0
6	Checksum	sum of bytes 1 to 5, modulo 256

The latter pages contain flowcharts to be used as guides in developing your code.

5.0 M-300 Data Memory

The M-300 Data Memory locations described below may be changed to tailor the sensor's operation to your particular application. The M-300 will verify that you stay within product limits for proper operation. If you write invalid data to any location, the M-300 sensor will replace the invalid data with the product default values after a re-boot command or next power up. Common practice is to verify the location you written to with the Read command (see page 6).

5.1 M-300 Data Memory (General)

5.1.1 ID Tag is in Data Memory address **40**. Values in this location must be between **1** and **32**. This location requires a special unlock command to enable writing to this location. See page 5 for details. The default value is **1**.

5.1.2 User Description Field is in Data Memory address **41** thru **72**. These values must be ASCII codes from **32** through **126**. The default values are **32** (ASCII spaces).

5.1.3 Voltage Output Operating Mode is in Data Memory address **85**. This location defines the operating mode of the Sensor's Voltage Output. A **"0"** in this location operates the Voltage Output in a linear mode. The parameters that control the slope and min/max voltage values of the voltage output are located in data memory locations *Zero Setpoint Distance*, *Zero Setpoint Voltage Value*, *Span Setpoint Distance*, and *Span Setpoint Voltage Value* (see page 11). A **"1"** in this location operates the Voltage Output as switch. The parameters that control the switch points are located in data memory *Close Setpoint Distance*, *Far Setpoint Distance*, and *Switch Mode Output Operation* and *Setpoint Output Hysteresis* (see page 12).

5.1.4 Average is in Data Memory address **91**. This location is defined as follows: **0**=ave. of 1, **1**=ave. of 2, **2**=ave. of 4, **3**=ave. of 8, **4**=ave. of 16, **5**=ave. of 32, **6**=ave. of 64, **7**=ave. of 128, **8**=ave. of 256, **9**=ave. of 512, and **10**=ave. of 1024. The maximum average for the "Rolling" average type is 32 (or index value of 5). The default value is **0**.

5.1.5 Average Type is in Data Memory address **92**. This location is defined as follows: **"0"** = Rolling and **"1"** = Boxcar. By definition, a Rolling average uses the latest samples where each new sample replaces the oldest sample. A Boxcar average takes the selected number of samples before outputting the average reading, then starts a new average. The default value is **0** (Rolling).

5.1.6 No Echo Time Out is in Data Memory address **93**. This location is programmable from **1** to **254** representing the amount of consecutive missed echoes before the sensor reaches a loss of echo condition. This parameter is independent of the Average parameter. The default value is **1**.

5.1.7 Trigger Mode is in Data Memory address **94**. This location is defined as follows: **"0"** establishes normal operation or internal self triggering at a rate programmed by the Sample Rate (data memory location **100-103**). A **"1"** in this location places the sensor in a software trigger mode where a computer or other host is required to initiate the sensor to transmit (see Software Trigger command on page 7). The default value is **0** (internal).

5.1.8 Sample Rate is in Data Memory address 100 thru 103. This 4 byte location represents the sampling time for which the sensor transmits its ultrasonic pulse. Address 100 is the LSB thru 103 being the MSB. Resolution for all sensor model M-300/210 is 200nS/bit, model M-300/150 and M-301/140 is 400nS/bit, and model M-300/95 is 800nS/bit. The default value for all models is 10Hz.

5.1.9 Temperature Compensation is in Data Memory address **95**. This location is defined as follows: “0” = internal probe or “1” = manual temperature (see location 96). The default value is **0** (internal probe). The formula for the speed of sound compensation is:

$$c = 789.9147 * \text{SQRT}(\text{temperature in } ^\circ\text{C} + 273) \text{ inches/sec}$$

For round trip to get range, divide the above formula by 2.

5.1.10 Manual Temperature Override is in Data Memory address **96**. When address **95** is set to 1, Manual Temperature operation is in effect and the value in this location (**96**) is used in calculating the target distance. The temperature is defined as:

$$\text{Temp } ^\circ\text{C} = (\text{data memory } \mathbf{96} * 0.48876) - 50$$

5.1.11 Self Heating Correction is in Data Memory address **24**. This location is defined as follows: “0” corrects for a self-heating error immediately at power up and is based on the input power supply voltage. The sensor’s self heating time is approximately 30 minutes where the sensor’s temperature probe will measure slightly low and will correct in time (30 min). This will give a slight error in reporting the range during this initial power up period (worst case error at power up). In most processes, the sensor is powered continuously, so it only affects the initial power up cycle. Subsequent power cycles (low off duty cycle) will report the temperature accurately.

When applications requires a sensor to be occasionally powered (very low ON duty cycles), setting this location to “1” disables self heating correction and will properly measure the ambient temperature. Note that if self heating is disabled and the sensor it powered continuously, then an error in reading the temperature will occur. The default value is **0** (self heating correction enabled).

5.1.12 Error Flags is in Data Memory address **104**. These are set when the sensor is in a fault condition. If **bit 0** is set, then at least one Data Memory location was programmed beyond the sensor limits and a factory default value replaced the data in error. The user should validate all Data Memory locations since more than one location could have been replaced. This particular error requires user intervention to clear by writing a “0” to this location.

Other errors indicators are **bit1** for a Brown Out error due to a low power supply. **Bit 2** for an internal Temperature Probe Fault. And **bit 3** for an internal Signal Detect Error. Errors indicated by bits 2 and 3 are self-clearing and the sensor will try to recover on its own. The Brown Out error flag can be cleared by writing a zero to its location. It is possible for the M-300 to continue to operate, even with this Brown Out flag set. However, users should check the power supply if this continues to be set.

5.1.13 Enable 4” Min Sensing Distance (M3x0/150 only) is in Data Memory address **105**. This enables closer sensing range. This location is defined as follows: “0” = disabled or 7” minimum sensing range or “1” = enabled or 4” minimum sensing range. Enabling this feature requires 2 ping cycles to obtain target range.

NOTE: If sensor is set up for Manual trigger, sensor must be requested for at least 2 software trigger commands to obtain a valid range report (if average=1). Disabling this setting a updated range report occurs on every ping (average=1).

5.2 M-300 Data Memory (Linear Mode Parameters)

5.2.1 Zero Setpoint Distance is in Data Memory address **73-74**. This 2 byte memory location represents the distance for the *Zero Setpoint Voltage Value* for the voltage output operating in the Linear Mode. The Voltage Output will operate linearly when a target is detected between this Zero Setpoint Distance and the Span Setpoint Distance. These 2 bytes are defined as **74** being the MSB and **73** being the LSB having a value of 128 times the range in inches¹. The default value is the Sensor's minimum specified distance and the limits are the sensors minimum and maximum specified ranges and must not equal the *Span Setpoint Distance*.

5.2.2 Zero Setpoint Voltage Value is in Data Memory address **77-78**. This 2 byte memory location is the voltage value for the *Zero Setpoint Distance* and is used when operating in the Linear Mode. The resolution for this 2 byte value is 1mV/bit with address **78** being MSB and **77** being LSB. The default value is **0** (0V).

5.2.3 Span Setpoint Distance is in Data Memory address **75-76**. This 2 byte memory location represents the distance for the *Span Setpoint Voltage Value* for the voltage output operating in the Linear Mode. The Voltage Output will operate linearly when a target is detected between the Zero Setpoint Distance and this Span Setpoint Distance. These 2 bytes are defined as **76** being the MSB and **75** being the LSB having a value of 128 times the range in inches¹. The default value is the Sensor's maximum specified distance and the limits are the sensors minimum and maximum specified ranges and must not equal the *Zero Setpoint Distance*.

5.2.4 Span Setpoint Voltage Value is in Data Memory address **79-80**. This 2 byte memory location is the voltage value for the *Span Setpoint Distance* and is used when operating in the Linear Mode. The resolution for this 2 byte value is 1mV/bit with address **80** being MSB and **79** being LSB. The default value is **10,000** (10.00V).

5.2.5 Loss of Echo Voltage Value is in Data Memory address **86-87**. This value represents the voltage output when the sensor is in the *No Echo Condition* (see No Echo Timeout address 93 on page 9). The resolution for this 2 byte value is 1mV/bit with address **87** being MSB and **86** being LSB. The default value is **10250** (10.25V).

5.2.6 Voltage Output Calibration is in Data Memory address **22-23**. This 2 byte location represents the 10.00V calibration value. The factory calibrates this parameter, but it may be adjusted to your instrument. The limits are from **900** to **1023**.

Note 1: Example for a range value of 37.75" saved in data memory would be $37.75 \times 128 = 4832_{10}$ or $12E0_{16}$. Thus in data memory store MSB= 12_{16} and LSB= $E0_{16}$ (MSB= 18_{10} and LSB= 224_{10})

5.3 M-300 DATA MEMORY (Switch Mode Parameters)

5.3.1 Close Setpoint Distance is in Data Memory address **81-82**. This 2 byte memory location is the distance used to establish a zone for the Voltage Output when operating in the Switch Mode. The 2nd setpoint used to create these zones is the *Far Setpoint Distance*. See *Switch Mode Output Operation* below for details on how the voltage output will operate. These 2 bytes are defined as **82** being the MSB and **81** being the LSB having a value of 128 times the range in inches (see note 1 previous page). This value must be less than the *Far Setpoint Distance*. The default value is the Sensor's minimum specified distance.

5.3.2 Far Setpoint Distance is in Data Memory address **83-84**. This 2 byte memory location is the distance used to establish a zone for the Voltage Output when operating in the Switch Mode. The 1st setpoint used to create these zones is the *Close Setpoint Distance*. See *Switch Mode Output Operation* below for details on how the voltage output will operate. These 2 bytes are defined as **84** being the MSB and **83** being the LSB having a value of 128 times the range in inches (see note 1 previous page). This value must be greater than the *Close Setpoint Distance*. The default value is the Sensor's maximum specified distance.

5.3.3 Switch Mode Output Operation is in Data Memory address **88**. This data location is used to establish what state the voltage output will be in when a target is detected within a particular zone created by the Close and Far Setpoint Distances (subject to Hysteresis, see below) when operating in the Switch Mode. The default value is **0**. The data byte is parsed as follows:

bit 0: No Echo

0 = No Echo Vout=0V , Echo present Vout=10V

1 = No Echo Vout=10V, Echo present Vout=0V

bit 1: Target > Far Setpoint Distance

0 = If Target > Far Setpoint Distance, then Vout = 0V

1 = If Target > Far Setpoint Distance, then Vout = 10V

bit 2*: Target between Close and Far Setpoint Distances (* bit 3 = 0 for this function, else see bit 3)

0 = Target Present between Close and Far Setpoint Distances, Vout=0V

1 = Target Present between Close and Far Setpoint Distances, Vout=10V

bit 3: No Change for Target between Close and Far Setpoint Distances

0 = See bit 2 for operation of targets between Close and Far Setpoint Distances

1 = No change in voltage output when targets enter between Close & Far Setpoint Distances (setting this to 1 will disable function of bit 2)

bit 4: Target < Close Setpoint Distance

0 = If Target < Close Setpoint Distance, then Vout = 0V

1 = If Target < Close Setpoint Distance, then Vout = 10V

5.3.4 Setpoint Output Hysteresis is in Data Memory address **90**. This location specifies the amount of hysteresis in %. The Close Setpoint Distance, Far Setpoint Distance, and Hysteresis must be chosen so that the Far Setpoint Distance with hysteresis applied is greater than the Close Setpoint Distance. This parameter is used when operating in the Switch Mode. The limits are **0** to **75%**. Hysteresis is defined as the distance between the operating point when a target approaches a setpoint and the release point when the target moves away from the setpoint towards its original position. The default value is **5** (percent).

5.3.5 Maximum Sensing Range is in Data Memory address **98-99**. This programmed value limits how far the sensor detects objects. These 2 bytes are defined as **99** being the MSB and **98** being the LSB having a value of 128 times the range in inches (see note 1 previous page). This parameter can be useful if you would like to eliminate a fixed background target and have the sensor indicate it as "No Echo". The default value is the Sensor model maximum specified sensing range.

5.4 M-300 DATA MEMORY (Sensitivity Adjustment Parameters)

The M-300 Sensor has a sensitivity (threshold) adjustment that can set both in amplitude and in time where it occurs. Massa has developed a series of adjustments as seen the in M-300 Software drop down menu. This includes *Normal*, *Normal High-Temperature*, *Low*, *Very Low*, *High* and *Very High*. Most applications should use the *Normal* setting. However applications such as the sensor being in a very hot environment (over 130°F) may want to select *Normal High-Temperature*. *High* settings improve acquiring a weak target, but may have other issues like detecting unwanted targets, so use these *High* settings with care. In applications such as a sensor aiming down a narrow pipe, the *Low* setting may be selected to avoid side reflections. Described below are the Data Memory locations that affect the sensitivity adjustment of the sensor. However it is highly recommended that if you change from the *Normal* setting that you fully evaluate operation of the sensor in your application. The M-300 Software has a menu item that displays the ultrasonic signals and will show the threshold levels as programmed.

5.4.1 Threshold Voltage #1 is in Data Memory address **30**. This is the initial voltage level set. The value is indexed from **1** to **18** and is defined as:

1=1.25V, **2**=1.41V, **3**=1.46V, **4**=1.56V, **5**=1.67V, **6**=1.72V, **7**=1.88V, **8**=2.03V, **9**=2.08V, **10**=2.19V, **11**=2.29V, **12**=2.34V, **13**=2.50V, **14**=2.66V, **15**=2.71V, **16**=2.81V, **17**=2.92V, **18**=2.97V.

5.4.2 Threshold Voltage #2 is in Data Memory address **31**. This is the next level change that can be set and will occur at the timing parameter *Switch time for Threshold #2*. The value is indexed from **1** to **18** and as described in *Threshold Voltage #1*. However, programming this location to a **0** will turn off this voltage level change.

5.4.3 Threshold Voltage #3 is in Data Memory address **32**. This is the next level change that can be set and will occur at the timing parameter *Switch time for Threshold #3*. The value is indexed from **1** to **18** and as described in *Threshold Voltage #1*. However, programming this location to a **0** will turn off this voltage level change.

5.4.4. Threshold Voltage #4 is in Data Memory address **33**. This is the next level change that can be set and will occur at the timing parameter *Switch time for Threshold #4*. The value is indexed from **1** to **18** and as described in *Threshold Voltage #1*. However, programming this location to a **0** will turn off this voltage level change.

5.4.5 Switch Time for Threshold Voltage #2 is in Data Memory address **34-35**. This 2 byte value represents the time, from when the sensor sends it ultrasonic pulse to where the voltage level changes to *Threshold Voltage #2* value. The MSB is stored in **35** and the LSB is in **34**. See note below for the defined unit value.

5.4.6 Switch Time for Threshold Voltage #3 is in Data Memory address **36-37**. This 2 byte value represents the time, from when the sensor sends it ultrasonic pulse to where the voltage level changes to *Threshold Voltage #3* value. The MSB is stored in **37** and the LSB is in **36**. See note below for the defined unit value.

5.4.7 Switch Time for Threshold Voltage #4 is in Data Memory address **38-39**. This 2 byte value represents the time, from when the sensor sends it ultrasonic pulse to where the voltage level changes to *Threshold Voltage #4* value. The MSB is stored in **39** and the LSB is in **38**. See note below for the defined unit value.

Note: The Switch Time for Threshold Voltage is model dependant. The M-300/210 is 200nS per bit, M-300/150 and M-301/140 is 400nS per bit, and the M-300/95 is 800nS per bit.

6.0 M-300 Ultrasonic Waveform Operation

6.1 Description

The M-300 Sensor has the ability to retrieve the ultrasonic waveform for analysis. This can be used to diagnose more difficult applications or simply to save the signal waveform as a record in your application. The M300 Software can display the waveform and can retrieve previously saved waveforms.

6.2 General Operation

Acquiring the waveform from the M-300 Sensor with one sensor on-line is performed by the 'Ultrasonic Waveform' command (see Section 6.4). However if more than one sensor is on-line, then 'Disable Communications' commands are necessary to avoid the overburden of communications data to the other sensors (see Section 6.3). Since the sensor's memory is limited, the waveform must be obtained in several ultrasonic pulses. Request for this ultrasonic waveform will be returned with sequential packets of 80 bytes from the sensor and the quantity of these 80 byte packets is model dependant. The waveform is not a single pulsed snapshot of the ultrasonic signal but is pieced together from several pulses. It is a valuable tool for diagnosing sensing issues.

6.3 Disable Communications Commands

If there is more than one sensor on-line, then it is imperative to temporarily disable communications for the sensors that are not sending waveform data. The first step is to send a 15mS 'Disable Communications' command to the sensor from which you want to retrieve the waveform as shown below.

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32 (sensor acquiring waveform)
3	Request Code	110 (Disable Communications)
4	Delay amount (LSB)	44
5	Delay amount (MSB)	1
6	Checksum	sum of bytes 1 to 5, modulo 256

Follow the above command with a much longer global 'Disable Communications' command to all other sensors with the time based on the model from which you are acquiring the waveform from. See below.

<u>Byte</u>	<u>Description</u>	<u>Value</u>
1	Sensor Request	170
2	Sensor ID Tag No.	0 (global, all sensors)
3	Request Code	110 (Disable Communications)
4	Delay amount (LSB)	see table below
5	Delay amount (MSB)	see table below
6	Checksum	sum of bytes 1 to 5, modulo 256

<u>Model for Ultrasonic Waveform That is Being Requested</u>	<u>Minimum Global Disable Time to All Other Sensors</u>	<u>Byte 4</u>	<u>Byte 5</u>
M-300/210	600mS	198	45
M-300/150	1000mS	75	76
M-300/95	1600mS	18	122

The resolution of the 'Disable Communications' time is approximately 51.2uS.

6.4 Request Ultrasonic Waveform

Once all the 'Disable Communications' commands are executed (when more than one sensor is on-line), then send the Ultrasonic Waveform command shown below to the sensor acquiring the waveform only after the 15mS time to 'Disable Communications' has expired.

Byte	Description	Value
1	Sensor Request	170
2	Sensor ID Tag No.	1 to 32
3	Request Code	100 (Ultrasonic Waveform Request)
4	Ping Type	0=low power, 1=high power (model 150 options only, model 95 set to 0)
5	Placeholder byte	0
6	Checksum	sum of bytes 1 to 5, modulo 256

The response from the M300 Sensor will be waveform data only. No header or checksum information is contained. The total number of bytes of the waveform is model dependent as shown in the table below. The 'Pulses Req.' column represents how many times the sensor has to send a transmit burst and the 'Total Acq. Time' represents the time required to obtain the entire waveform. Sensor samples 80 bytes per pulse which is sent as a block of data and then repeated until the entire waveform is sent. To scale the waveform properly, the column '1st byte time' represents the time when the waveform data started sampling after the ultrasonic transmit burst while the 'Last byte time' represents the time of the waveform's last data byte. For model 150 sensors, obtain a low power and then a high power waveform for analysis.

Sensor Model	Waveform Bytes	Pulses Req.	Total Acq. Time	1 st byte time	Last byte time
M-300/210	400	5	240mS	57uS	9755uS
M-300/150	800	10	480mS	70uS	18676uS
M-300/95	1680	21	1008mS	104uS	39272uS


To convert the time data to distance in inches, use the formula below:

$$\text{Distance (inches)} = (\text{Time (sec)} * 789.9 * \text{SQRT (Temperature } ^\circ\text{C} + 273)) / 2$$

The data byte represents the amplitude information and its formula is:


$$\text{Amplitude (in volts)} = 0.0195 * \text{waveform byte}$$

Here is plot from an M-300/210 with a target at 15 inches. The pulse at the beginning of the waveform represents the transmit burst followed by the main echo from the target at 15" followed by subsequent multiple reflections.




7.0 Flowcharts

M-300 Flowchart for Status Information on Multiple Sensors



M-300 Flowchart for Writing to Data Memory



M-300 Flowchart for Reading Data Memory

